



Contenuto Nella Confezione:



Assemblaggio Espositore:




1. Come primo passo consigliamo l'assemblaggio di tutte le diverse astine contenute nella confezione:

1.1. Unire i due tubi (c) tramite il connettore (g) per formare un'astina da 66cm. All'estremità di questa astina verrà posizionata la valvolina (e). Questa astina è la più lunga e resistente tra tutte, è in grado di sostenere palloncini in lattice, mylar o bubble fino ad un MAX di 18 - 19 Pollici.

1.2. Unire i tubi (b) e (a) tramite i connettori (f), questo formerà 3 astine da 55cm dove poi verranno posizionate le valvoline (d). Queste astine sono in grado di sostenere palloncini in lattice, mylar o bubble fino ad un MAX di 10 - 12 Pollici.

1.3 Unire i restanti tubi (b) alle valvoline (d), questo formerà 3 astine da 33cm. Queste astine sono in grado di sostenere palloncini in lattice, mylar o bubble fino ad un MAX di 10 - 12 Pollici.

2



2. Il prossimo passo è posizionare le astine sulla base di appoggio (h) tramite i punti di ancoraggio. L'astina più grande verrà posizionata centralmente, mentre il resto dove meglio credete.

3. Adesso bisogna solo inserire i palloncini per completare l'espositore.


Altezza MAX: 70cm

3






Inside the package:



Balloon Tree Assembly:




1. As a first step, we recommend the assembly of all the different rods contained in the package:

1.1. Join the two tubes (c) through the connector (g) to form a 66cm rod. At the end of this rod, insert the valve (e). This rod is the longest and most resistant, it's able to support latex, mylar or bubble balloons up to a MAX of 18 - 19 Inches.

1.2. Join the tubes (b) and (a) through the connectors (f), this will form 3 rods of 55cm where the small valves (d) will be positioned. These rods are able to support latex, mylar or bubble balloons up to a MAX of 10 - 12 Inches.

1.3 Join the remaining tubes (b) to the valves (d), this will form 3 rods of 33cm. These rods are capable to support latex, mylar or bubble balloons up to a MAX of 10 - 12 Inches.

2



Anchor points

2. The next step is to place the rods on the support base (h) via the anchor points. The largest rod will be positioned centrally, while the rest can be placed randomly.

3. Now you just have to place the balloons to complete the display.

MAX height: 70cm

3

